



TABLE 5C: CONTOUR OVERLAY (USES 7½ MINUTE QUAD.)

DISTANCE SCALES



SLOPE



1. PLACE CIRCLE OVER AREA.
2. COUNT CONTOUR LINES WITHIN CIRCLE (DO NOT COUNT ACROSS RIDGES OR CREEKS).
3. IN TABLE BELOW FIND NUMBER OF CONTOUR LINES COUNTED (NEXT TO PROPER CONTOUR INTERVAL FOR YOUR QUAD) AND READ % SLOPE AT BOTTOM.

(1000 FT. I.D.)

		NUMBER OF CONTOUR LINES COUNTED									
CONTOUR INTERVAL	20	12	20	28	30	32	36	40			
	40	6	10	14	15	16	18	19			
	50	5	8	11	12	13	14	15			
	80	3	5	7	8	8	9	10			
PERCENT SLOPE	25	40	55	60	65	70	75				